

Supply Schedules 2011

Suction

No. 129822 - Valid from 01.11.2011

Suggested sales prices. V.A.T. excluded.

This price list is valid from 01.11.2011 and until the publication date of the subsequent list. Note: our price lists are regularly updated at short notice. Please make sure you have the current price list before you order by calling us (+49-(0)40-547 02-0) or by using your customer log-in to check our Web site (www.weinmann.de). All previously issued price lists lose their validity as of the publication date of the newest price list. We reserve the right to make changes to designs and equipment, especially those resulting from ongoing development of new production series, without prior notice. WEINMANN is entitled to exclusive use of any and all forms of copyright related to this publication unless it grants express permission to another party.

A minimum quantity surcharge of 10 € applies to deliveries in foreign countries with a total value of less than 300 €.

Table of Contents

	Page
Suction	3
Suction Devices	3
ACCUVAC Rescue	3
Accessories and Replacement Parts for ACCUVAC Rescue	3
Instructions for use	5
ACCUVAC Basic	5
Accessories and Replacement Parts for ACCUVAC Basic	7
Instructions for use	8
Accessories and Replacement Parts for Reusable Collection Canister	9
Accessories and Replacement Parts for Disposable Collection Canister	10
MANUVAC	11
Accessories and Replacement Parts for MANUVAC	12
Instructions for use	12
OMNIVAC	12
Accessories and Replacement Parts for OMNIVAC	13
Instructions for use	14

Suction

Suction Devices

ACCUVAC Rescue

WM 10600	ACCUVAC Rescue with reusable canister, electronic suction pump with 12V connection cable to motor vehicle power supply/ACCUVAC (WM 10650), Reusable collection canister with bacteria filter, aspiration hose with finger tip control and one replacement filter (WM 10630)
WM 10608	ACCUVAC Rescue with disposable canister, electronic suction pump with 12V connection cable to motor vehicle power supply/ACCUVAC (WM 10650), Disposable collection canister with overflow filter and aspiration hose with finger tip control (WM 10730)
WM 10620	ACCUVAC Rescue with reusable canister, electronic suction pump with 12V connection cable to motor vehicle power supply/ACCUVAC (WM 10650), Reusable collection canister, complete, (WM 10630), Accessory bag (WM 10655), Wall mounting set (WM 15208)
WM 10609	ACCUVAC Rescue with disposable canister, electronic suction pump with 12V connection cable to motor vehicle power supply/ACCUVAC (WM 10650), Disposable collection canister, complete, (WM 10730) Accessory bag (WM 10655), Wall mounting set (WM 15208)

Accessories and Replacement Parts for ACCUVAC Rescue

WM 10655	Accessory bag for ACCUVAC
WM 2610	Power pack and battery charger for 100-240 Volt AC to 12 Volt DC, including power cable "European plug" (complies with EN 50075) and user manual (for ACCUVAC, MODUL CapnoVol, MEDUMAT Elektronik) For use with ACCUVAC Basic WM 10700 or WM 10709 please also order connection cable

	WM 10650	Main power cable AU/NZ type I
WM 27016		Main power cable GB type G
WM 27018		Main power cable IN type M
WM 27013		Wall mounting for ACCUVAC, including installation set For suspension on standard hospital rail please order additionally: Holding plate for standard hospital rail (WM 15845) For fixation on standard hospital rail please order additionally: Holding plate for standard hospital rail (WM 15845) and attachment set with two adapters for standard hospital rail (WM 15805) For fixation on pole Ø 19 mm - 40 mm please order additionally: Attachment set for rail bracket (WM 15806)
WM 15208		Wall mounting for power pack and battery charger for ACCUVAC and MODUL CapnoVol for direct wall mounting (appropriate screws for ACCUVAC and MODUL CapnoVol for wall mounting to be supplied by customer) For suspension on standard hospital rail please order additionally: Holding plate for standard hospital rail (WM 15845) For fixation on standard hospital rail please order additionally: Holding plate for standard hospital rail (WM 15845) and attachment set with one adapter for standard hospital rail (WM 15795) For fixation on pole Ø 19 mm - 40 mm please order additionally: Attachment set for rail bracket (WM 15806)
WM 15844		Holding plate for standard hospital rail, can be combined with: - Wall mounting for ACCUVAC (WM 15208), - Holder for power pack and battery charger for ACCUVAC and MODUL CapnoVol (WM 15844), - Holder for power supply unit and charger for MEDUMAT Transport (WM 15846) and holder for rechargeable battery pack (WM 15847)
WM 15845		Attachment set for standard hospital rail with one adapter
WM 15795		Attachment set for standard hospital rail with two adapters
WM 15805		Attachment set for pole mount Ø 19 mm - 40 mm
WM 15806		12-volt connection cable for ACCUVAC
WM 10650		Fuse, DIN 72581-A8 for automobile plug
WM 10673		Fuses, power supply (F1)/(F100) and rechargeable battery pack (F2)/(F101) for ACCUVAC Rescue and Basic
WM 2692		

WM 10635	Sealing ring for reusable collection canister
WM 10665	Noise suppressor for ACCUVAC Rescue and Basic
WM 10623	Hose holding plate, red, for ACCUVAC Rescue
WM 10647	Ni-Cd power pack (only for ACCUVAC Rescue)
WM 15396	Set of catch release keys, red, for ACCUVAC Rescue

Instructions for use

User manuals can be downloaded free of charge from www.weinmann.de

WM 16135	User Manual for ACCUVAC Rescue, DE
WM 16136	User Manual for ACCUVAC Rescue, EN
WM 16230	User Manual for ACCUVAC Rescue, FR
WM 16258	User Manual for ACCUVAC Rescue, IT
WM 16607	User Manual for ACCUVAC Rescue, NL
WM 16669	User Manual for ACCUVAC Rescue, PT
WM 16227	User Manual for ACCUVAC Rescue, ES
WM 66255	User Manual for ACCUVAC Rescue, PL
WM 66256	User Manual for ACCUVAC Rescue, ZH
WM 66257	User Manual for ACCUVAC Rescue, RU
WM 66630	Instructions for use ACCUVAC Rescue, TR
WM 66631	User Manual ACCUVAC Rescue, SV
WM 66632	User Manual ACCUVAC Rescue, DA
WM 16189	Instructions for use for Disposable Collection Canister, DE
WM 16233	Instructions for use for Disposable Collection Canister, EN, FR, IT
WM 16780	Instructions for use for Disposable Collection Canister, ES
WM 16190	Instructions for use for Reusable Collection Canister, DE
WM 16235	Instructions for use for Reusable Collection Canister, EN, FR, IT
WM 16728	Instructions for use for Reusable Collection Canister, DA
WM 16781	Instructions for use for Reusable Collection Canister, ES
WM 16209	Assembly instructions for wall mounting ACCUVAC Rescue, DE / GB / FR
WM 66035	User manual power pack and battery charger, DE
WM 66036	User manual power pack and battery charger, EN
WM 66037	User manual power pack and battery charger, FR

ACCUVAC Basic

WM 10709	<p>ACCUVAC Basic with reusable canister, electric aspiration pump, with plug-in charger, complete (WM 10750), Reusable collection canister with bacteria filter, aspiration hose with finger tip control and one replacement filter (WM 10630)</p>
WM 10700	<p>ACCUVAC Basic with disposable canister, electric aspiration pump, with plug-in charger, complete (WM 10750), Disposable collection canister with overflow filter and aspiration hose with finger tip control (WM 10730)</p>
WM 10705	<p>ACCUVAC Basic with disposable canister, electronic suction pump with 12V connection cable to motor vehicle power supply/ ACCUVAC (WM 10650), Disposable collection canister, complete, (WM 10730), Accessory bag (WM 10655), Wall mounting set (WM 15208)</p>
WM 10715	<p>ACCUVAC Basic with reusable canister, electronic suction pump, with 12V connection cable to motor vehicle power supply/ ACCUVAC (WM 10650), Reusable collection canister, complete, (WM 10630), Accessory bag (WM 10655), Wall mounting set (WM 15208)</p>
WM 10720	<p>ACCUVAC Basic with disposable canister, electric aspiration pump, user manuals in French with 12V connection cable to motor vehicle power supply/ ACCUVAC (WM 10650), Power pack and battery charger for 100-240 Volt AC to 12 Volt DC (WM 2610) Disposable collection canister with overflow filter and aspiration hose with finger tip control (WM 10730) User manual French (WM 16231)</p>
WM 10727	<p>ACCUVAC Basic with reusable canister, electric aspiration pump, user manuals in French with 12V connection cable to motor vehicle power supply/ ACCUVAC (WM 10650), Power pack and battery charger for 100-240 Volt AC to 12 Volt DC (WM 2610) Reusable collection canister with bacteria filter, aspiration hose with finger tip control and one replacement filter (WM 10630)</p>

Accessories and Replacment Parts for ACCUVAC Basic

WM 10655	Accessory bag for ACCUVAC
WM 2610	Power pack and battery charger for 100-240 Volt AC to 12 Volt DC, including power cable "European plug" (complies with EN 50075) and user manual (for ACCUVAC, MODUL CapnoVol, MEDUMAT Elektronik) For use with ACCUVAC Basic WM 10700 or WM 10709 please also order connection cable WM 10650
WM 27016	Main power cable AU/NZ type I
WM 27018	Main power cable GB type G
WM 27013	Main power cable IN type M
WM 15208	Wall mounting for ACCUVAC, including installation set For suspension on standard hospital rail please order additionally: Holding plate for standard hospital rail (WM 15845) For fixation on standard hospital rail please order additionally: Holding plate for standard hospital rail (WM 15845) and attachment set with two adapters for standard hospital rail (WM 15805) For fixation on pole Ø 19 mm - 40 mm please order additionally: Attachment set for rail bracket (WM 15806)
WM 15844	Wall mounting for power pack and battery charger for ACCUVAC and MODUL CapnoVol for direct wall mounting (appropriate screws for ACCUVAC and MODUL CapnoVol for wall mounting to be supplied by customer) For suspension on standard hospital rail please order additionally: Holding plate for standard hospital rail (WM 15845) For fixation on standard hospital rail please order additionally: Holding plate for standard hospital rail (WM 15845) and attachment set with one adapter for standard hospital rail (WM 15795) For fixation on pole Ø 19 mm - 40 mm please order additionally: Attachment set for rail bracket (WM 15806)
WM 15845	Holding plate for standard hospital rail, can be combined with: - Wall mounting for ACCUVAC (WM 15208), - Holder for power pack and battery charger for ACCUVAC and MODUL CapnoVol (WM 15844), - Holder for power supply unit and charger for MEDUMAT Transport (WM 15846) and holder for rechargeable battery pack (WM 15847)
WM 15795	Attachment set for standard hospital rail with one

	adapter
WM 15805	Attachment set for standard hospital rail with two adapters
WM 15806	Attachment set for pole mount Ø 19 mm - 40 mm
WM 10650	12-volt connection cable for ACCUVAC
WM 10673	Fuse, DIN 72581-A8 for automobile plug
WM 10750	Charger, complete, only for ACCUVAC Basic with euro plug and adapters for US, GB and AU
WM 2692	Fuses, power supply (F1)/(F100) and rechargeable battery pack (F2)/(F101) for ACCUVAC Rescue and Basic
WM 10635	Sealing ring for reusable collection canister
WM 10665	Noise suppressor for ACCUVAC Rescue and Basic
WM 10723	Hose holder, green for ACCUVAC Basic
WM 10747	Lead storage battery for ACCUVAC Basic
WM 15397	Set of catch release keys, green, for ACCUVAC Basic

Instructions for use

User manuals can be downloaded free of charge from www.weinmann.de

WM 16137	Instructions for use ACCUVAC Basic, DE
WM 67330	Assembly instructions for wall mountings: for power pack and battery charger for ACCUVAC and MODUL CapnoVol, for power supply unit and charger for MEDUMAT Transport and for rechargeable battery pack for MEDUMAT
WM 67320	Assembly instructions for holding plate for standard hospital rail
WM 67080	Assembly instructions attachment set for standard hospital rail, DE, EN, FR
WM 67090	Assembly instructions attachment set for rail bracket, DE, EN, FR
WM 16138	Instructions for use ACCUVAC Basic, EN
WM 16231	Instructions for use ACCUVAC Basic, FR
WM 16670	Instructions for use ACCUVAC Basic, PT
WM 16236	Instructions for use ACCUVAC Basic, NL
WM 16234	Instructions for use ACCUVAC Basic, IT
WM 16727	Instructions for use ACCUVAC Basic, DA
WM 16779	Instructions for use ACCUVAC Basic, ES
WM 66260	User Manual ACCUVAC Basic, PL
WM 66261	User Manual ACCUVAC Basic, ZH
WM 66262	User Manual ACCUVAC Basic, RU
WM 66645	Instructions for use ACCUVAC Basic, TR
WM 66646	User Manual ACCUVAC Basic,

	EL
WM 66647	User Manual ACCUVAC Basic, CS
WM 66259	User Manual ACCUVAC Basic, SV
WM 66264	User Manual ACCUVAC Basic, ID
WM 16189	Instructions for use for Disposable Collection Canister, DE
WM 16233	Instructions for use for Disposable Collection Canister, EN, FR, IT
WM 16780	Instructions for use for Disposable Collection Canister, ES
WM 16190	Instructions for use for Reusable Collection Canister, DE
WM 16235	Instructions for use for Reusable Collection Canister, EN, FR, IT
WM 16728	Instructions for use for Reusable Collection Canister, DA
WM 16781	Instructions for use for Reusable Collection Canister, ES

Accessories and Replacement Parts for Reusable Collection Canister

WM 15261	Conversion set for reusable collection canister for ACCUVAC consists of: Set of reusable collection canister (WM 10630), set of holders for reusable collection canister (WM 15271)
WM 10630	Reusable collection canister, complete, for ACCUVAC consists of: collection canister, 1,000 ml (WM 10631), collection canister cover (WM 10636), Filter cover (WM 10632), Filter (WM 10675), Ball (WM 10643), Sealing ring (WM 10635), Suction hose 10/2,5 1300 mm (WM 10662), Endpiece with fingertip control (WM 10666), Reinforcing clamp (WM 10641)
WM 10631	Canister 1,000 ml, reusable collection canister
WM 10632	Filter cover for reusable collection canister
WM 10636	Cover for reusable collection canister
WM 10643	Ball for reusable collection canister
WM 15271	Set of holders for reusable collection canister for ACCUVAC Rescue and Basic, including fastening material
WM 10640	Holder for reusable collection canister
WM 15229	Set of rinsing glass for reusable collection canister for ACCUVAC consists of:

	collection canister 1,000 ml (WM 10631), holder set for reusable canister (WM 15271), fixing plate (WM 10728)
WM 10675	Bacteria filter for reusable collection canister for ACCUVAC Rescue and Basic
WM 15246	Bacteria Filter Set I for reusable collection canister for ACCUVAC (25 x WM 10675)
WM 15247	Bacteria Filter Set II for reusable collection canister for ACCUVAC (50 x WM 10675)
WM 15248	Bacteria Filter Set III for reusable collection canister for ACCUVAC (100 x WM 10675)
WM 10662	Suction hose 10 mm inner diameter, 1300 mm long, for reusable collection canister for ACCUVAC Rescue and Basic
WM 15307	Suction hose Set I for reusable collection canister for ACCUVAC (10 x WM 10662)
WM 15308	Suction hose Set II for reusable collection canister for ACCUVAC (20 x WM 10662)
WM 15309	Suction hose Set III for reusable collection canister for ACCUVAC (50 x WM 10662)
WM 10666	Endpiece with fingertip control for reusable collection canister for ACCUVAC Rescue and Basic
WM 15324	Set I Endpiece with fingertip control for reusable collection canister for ACCUVAC (10 x WM 10666)
WM 15325	Set II Endpiece with fingertip control for reusable collection canister for ACCUVAC (20 x WM 10666)
WM 15326	Set III Endpiece with fingertip control for reusable collection canister for ACCUVAC (50 x WM 10666)
WM 15363	Set of Reinforcing Clamps for reusable collection canister for ACCUVAC (1 x WM 10641)

Accessories and Replacement Parts for Disposable Collection Canister

WM 15262	Conversion set of disposable collection canister for ACCUVAC consists of: Set of disposable collection canister (WM 15268), Set of holders (WM 15172)
WM 15172	Set of holders for disposable collection canister for ACCUVAC Rescue and Basic

WM 15268	Set of disposable collection canister for ACCUVAC consists of: disposable collection canister, complete (WM 10730), connection hose (WM 10740)
WM 10740	Vacuum hose for disposable collection canister
WM 10737	Adapter for vacuum hose / disposable collection canister ACCUVAC
WM 10730	Disposable collection canister, complete, for ACCUVAC consists of: collection canister, 1,000 ml (WM 10731), disposable suction bag (WM 10732), suction hose with fingertip control (WM 10733)
WM 10731	Disposable collection canister, 1000 ml, without suction hose
WM 10732	Disposable suction bag for ACCUVAC Rescue and Basic with cover and overflow valve for disposable collection canister
WM 15226	Set I of Disposable suction bags for ACCUVAC with cover and overflow valve for disposable collection canister (10 x WM 10732)
WM 15227	Set II of Disposable suction bags for ACCUVAC with cover and overflow valve for disposable collection canister (20 x WM 10732)
WM 15228	Set III of Disposable suction bags for ACCUVAC with cover and overflow valve for disposable collection canister (50 x WM 10732)
WM 10738	T-shaped piece for disposable collection canister
WM 10733	Suction hose with fingertip control for disposable collection canister
WM 15327	Suction Hose Set I for disposable collection canister with fingertip control for ACCUVAC (10 x WM 10733)
WM 15328	Suction Hose Set II for disposable collection canister with fingertip control for ACCUVAC (20 x WM 10733)
WM 15329	Suction Hose Set III for disposable collection canister with fingertip control for ACCUVAC (50 x WM 10733)

MANUVAC

WM 10800	MANUVAC Manual Suction Pump
----------	-----------------------------

with mobile collection canister and 2-level hose

Accessories and Replacment Parts for MANUVAC

WM 15116	Suction hose set for MANUVAC
WM 2201	Silicone suction hose, 10/15 mm Ø, 280 mm
WM 2251	Secretions nozzle with fingertip control and stopper for MANUVAC und OMNIVAC
	The article contains the following substances included on the candidate list according to article 59 (1, 10) of Regulation (EC) No 1907/2006 (REACH) in a concentration above 0.1 % weight by weight: DEHP (CAS No. 117-81-7, EC No. 204-211-0) The packaging materials contain no substances included on the candidate list in a concentration above 0.1 % weight by weight.
WM 2252	Angled hose plug
WM 2261	Connection piece
WM 2281	Reflux valve
WM 5776	Hose, steramide, 4/7 Ø, 740 mm
WM 10801	Silicone suction hose, 1020 mm long
WM 10821	Collection canister for MANUVAC
WM 10822	Secretions cap, complete, for MANUVAC
WM 10823	Secretions cap for MANUVAC
WM 10825	Shut-off lever
WM 10842	Plate membrane

Instructions for use

User manuals can be downloaded free of charge from www.weinmann.de

WM 16030	User Manual für MANUVAC, DE
WM 16031	User Manual for MANUVAC , EN
WM 16032	User Manual for MANUVAC , FR
WM 16119	User Manual for MANUVAC , PL
WM 66240	User Manual für MANUVAC, IT
WM 66239	User Manual for MANUVAC, NL
WM 66241	User Manual für MANUVAC, ES

OMNIVAC

WM 2135	OMNIVAC Secretion aspiration equipment, with 500 ml and 1000 ml collection canister of polysulphone, with injector
WM 2205	OMNIVAC secretion aspiration equipment with 500 ml collection canister of polysulphone

	with regulation equipment and vacuum meter 0-1 bar
WM 2206	OMNIVAC secretion aspiration equipment with 1000 ml collection canister of polysulphone with regulation equipment and vacuum meter
WM 2275	OMNIVAC aspiration equipment with 500-ml collection canister of polysulfon, without injector
WM 2250	OMNIVAC aspiration equipment with two 500-ml collection canister of polysulfon, without injector
WM 2265	OMNIVAC aspiration equipment with 250-ml collection canister of polysulfon, with injector
WM 2280	OMNIVAC aspiration equipment with 250-ml collection canister of polysulfon, without injector

Accessories and Replacment Parts for OMNIVAC

WM 2190	Collection canister holder for two canisters (suitable for 500-ml and 1000-ml canisters), light grey, for PONY-carriage
WM 2245	Holder for two 500-ml collection canisters of polysulfon (for LIFE-STATION)
WM 2246	Holder for 250-ml collection canister of polysulfon (for case)
WM 2262	collection canister holder for 250-ml canister, swivels
WM 2298	Clamp for 500-ml and 1000-ml secretions containers of polysulfon (for portable system and tornister)
WM 2286	Screw-on injector
WM 2271	Collection canister of polysulfon, 1000 ml
WM 2272	Collection canister of polysulfon, 250 ml
WM 2273	Collection canister of polysulfon, 500 ml
WM 2182	Secretion cap, complete
WM 2254	Secretion cap, large
WM 2279	Reflux valve for OMNIVAC
WM 2201	Silicone suction hose, 10/15 mm Ø, 280 mm
WM 2203	Silicone suction hose, 6/10 mm Ø, 800 mm
WM 2251	Secretions nozzle with fingertip control and stopper for MANUVAC und OMNIVAC

The article contains the following
substances included on the candidate
list according to article 59 (1, 10) of

	Regulation (EC) No 1907/2006 (REACH) in a concentration above 0.1 % weight by weight: DEHP (CAS No. 117-81-7, EC No. 204-211-0) The packaging materials contain no substances included on the candidate list in a concentration above 0.1 % weight by weight.
WM 2252	Angled hose plug
WM 2261	Connection piece
WM 2289	Secretion nozzle
WM 2631	Secretion cap with regulator
WM 10948	Silicone suction hose, 10/15 mm Ø, 230 mm

Instructions for use

User manuals can be downloaded free of charge from www.weinmann.de

WM 16240	Instructions for use for OMNIVAC, DE
WM 16232	User Manual OMNIVAC EN